

**Legend for Condensing Units Wiring diagrams**  
**Légende de schémas électriques de Groupes de condensation**  
**Legende für Verflüssigungssätze Schaltplänen**

<b>A1</b>	<ul style="list-style-type: none"> <li>– <b>EC2 Controller</b></li> <li>– EC2 Régulateur électronique</li> <li>– <i>EC2 Regler</i></li> </ul>	<b>S10, Y10</b>	<ul style="list-style-type: none"> <li>– <b>Traxoil - Compressor 1</b></li> <li>– Traxoil - Compresseur 1</li> <li>– <i>Traxoil - Verdichter 1</i></li> </ul>
<b>B6</b>	<ul style="list-style-type: none"> <li>– <b>Discharge Temperature NTC thermistor</b></li> <li>– Sonde (NTC) de température de refoulement</li> <li>– <i>NTC Thermistor für die Vedichter Austrittstemperatur</i></li> </ul>	<b>S20, Y20</b>	<ul style="list-style-type: none"> <li>– <b>Traxoil - Compressor 2</b></li> <li>– Traxoil - Compresseur 1</li> <li>– <i>Traxoil - Verdichter 2</i></li> </ul>
<b>B10</b>	<ul style="list-style-type: none"> <li>– <b>Transducer Suction Pressure</b></li> <li>– Transmetteur de pression d'aspiration</li> <li>– <i>Drucktransmitter Niederdruck</i></li> </ul>	<b>S2</b>	<ul style="list-style-type: none"> <li>– <b>Low Pressure Switch</b></li> <li>– Pressostat basse pression</li> <li>– <i>Niederdruckshalter</i></li> </ul>
<b>B20</b>	<ul style="list-style-type: none"> <li>– <b>Transducer Discharge Pressure</b></li> <li>– Transmetteur de pression d'aspiration</li> <li>– <i>Drucktransmitter Hochdruck</i></li> </ul>	<b>S3.1</b>	<ul style="list-style-type: none"> <li>– <b>High Pressure Switch Compressor 1</b></li> <li>– Pressostat haute pression Compresseur 1</li> <li>– <i>Hochdruckshalter Verdichter 1</i></li> </ul>
<b>C1, C2</b>	<ul style="list-style-type: none"> <li>– <b>Capacitors</b></li> <li>– Condensateurs</li> <li>– <i>Kondensator</i></li> </ul>	<b>S3.2</b>	<ul style="list-style-type: none"> <li>– <b>High Pressure Switch Compressor 2</b></li> <li>– Pressostat haute pression Compresseur 2</li> <li>– <i>Hochdruckshalter Verdichter 2</i></li> </ul>
<b>E1</b>	<ul style="list-style-type: none"> <li>– <b>Cranckase Heater Compressor 1</b></li> <li>– Résistance de carter - Compresseur 1</li> <li>– <i>Kurbelgehäuseheizung - Verdichter 1</i></li> </ul>	<b>S4</b>	<ul style="list-style-type: none"> <li>– <b>Room Thermostat</b></li> <li>– Thermostat d'ambiance</li> <li>– <i>Raumthermostat</i></li> </ul>
<b>E2</b>	<ul style="list-style-type: none"> <li>– <b>Cranckase Heater Compressor 2</b></li> <li>– Résistance de carter - Compresseur 2</li> <li>– <i>Kurbelgehäuseheizung - Verdichter 2</i></li> </ul>	<b>S6.1</b>	<ul style="list-style-type: none"> <li>– <b>Discharge Gas Thermostat- Compressor 1</b></li> <li>– Thermostat de refoulement externe - Compresseur 1</li> <li>– <i>Druckgas Thermostat - Verdichter 1</i></li> </ul>
<b>F1...3</b>	<ul style="list-style-type: none"> <li>– <b>Fuse</b></li> <li>– Fusible</li> <li>– <i>Sicherung</i></li> </ul>	<b>S6.2</b>	<ul style="list-style-type: none"> <li>– <b>Discharge Gas Thermostat- Compressor 2</b></li> <li>– Thermostat de refoulement externe - Compresseur 2</li> <li>– <i>Druckgas Thermostat - Verdichter 2</i></li> </ul>
<b>H1, H2</b>	<ul style="list-style-type: none"> <li>– <b>Lamp – 1 LP, 2 HP</b></li> <li>– Lampe – 1 LP, 2 HP</li> <li>– <i>Storungslampe – 1 LP, 2 HP</i></li> </ul>	<b>T1</b>	<ul style="list-style-type: none"> <li>– <b>Transformer</b></li> <li>– Transformateur</li> <li>– <i>Transformator</i></li> </ul>
<b>K1, K2</b>	<ul style="list-style-type: none"> <li>– <b>Power Contactor</b></li> <li>– Contacteur</li> <li>– <i>Schutz</i></li> </ul>	<b>U1, B1</b>	<ul style="list-style-type: none"> <li>– <b>Fan Speed Controller</b></li> <li>– Control de la Vitesse du Ventilateur</li> <li>– <i>Drehzahlregelung Ventilator</i></li> </ul>
<b>K10, K20</b>	<ul style="list-style-type: none"> <li>– <b>Contacteur</b></li> <li>– Contacteur</li> <li>– <i>Schutz</i></li> </ul>	<b>Y1</b>	<ul style="list-style-type: none"> <li>– <b>Solenoid Valve Compressor 1</b></li> <li>– Électrovanne Compresseur 1</li> <li>– <i>Magnetventil Verdichter 1</i></li> </ul>
<b>M1, M2</b>	<ul style="list-style-type: none"> <li>– <b>Compressor Motor</b></li> <li>– Moteur de Compresseur</li> <li>– <i>Verdichtermotor</i></li> </ul>	<b>Y2</b>	<ul style="list-style-type: none"> <li>– <b>Solenoid Valve Compressor 2</b></li> <li>– Électrovanne Compresseur 2</li> <li>– <i>Magnetventil Verdichter 2</i></li> </ul>
<b>M10, M20</b>	<ul style="list-style-type: none"> <li>– <b>Fan Motor</b></li> <li>– Moteur de ventilateur</li> <li>– <i>Ventilatormotor</i></li> </ul>	<b>Y3</b>	<ul style="list-style-type: none"> <li>– <b>Solenoid Valve Digital</b></li> <li>– Électrovanne Digital</li> <li>– <i>Magnetventil Digital</i></li> </ul>
<b>Q1, Q2</b>	<ul style="list-style-type: none"> <li>– <b>Overload Circuit Braker</b></li> <li>– Disjoncteur</li> <li>– <i>Überstrom</i></li> </ul>	<b>Y4</b>	<ul style="list-style-type: none"> <li>– <b>Solenoid Valve Liquid</b></li> <li>– Électrovanne de liquide</li> <li>– <i>Magnetventil Flüssigkeit</i></li> </ul>